

# Carry All Tote



## Cutting

From the grass green fabric, cut:  
(2) 9-1/2" x 19" pieces

From the white-on-black fabric, cut:  
(2) 3" x 19" pieces  
(2) 2" x 29" pieces

From the teal fabric, cut:  
(2) 12-1/2" x 19" pieces  
(2) 3" x 19" pieces  
(1) Base template on page 55

From the multi-check print fabric, cut:  
(2) 13" x 31" pieces  
(1) Base template on page 55

From the Pellon® Décor Bond®, cut:  
(4) 3" x 19" pieces  
(2) 9-1/2" x 19" pieces  
(1) Base template on page 55

From the Pellon® Peltex® Ultra-Firm iron on, cut:  
(2) 12-1/2" x 19" pieces  
(1) Base template on page 55

From the natural cording, cut:  
(2) 18" lengths  
(1) 36" length

*Note: Put a piece of tape around the section of cording you are going to cut. Make the cut in the middle of tape. This will eliminate the cording expanding when handling it and pulling into handle strip.*

From the 1/4"-wide elastic, cut:  
(2) 19" lengths

WOF = width of fabric  
Sew with a 1/2" seam allowance

## Sewing Instructions

### Making the Outside Bag

1. Following manufacturer's directions, press the Décor Bond pieces to the wrong side of (2) 9-1/2" x 19" grass green pieces, (2) 3" x 19" white-on-black pieces, (2) 3" x 19" teal pieces and the teal base template piece.

## Yardage

- 1/2 yard grass green fabric
- 1/4 yard white-on-black fabric
- 1-1/4 yards teal fabric
- 7/8 yard multi-check print fabric
- 1 yard Pellon® Décor Bond
- 1 yard Pellon® Peltex® Single-sided Fusible Stabilizer
- 2 yards natural cording
- 1-1/8 yards 1/4"-wide elastic
- 4 1-1/2" grommets

*Note: All seam allowances are 1/2" unless otherwise noted.*